LE CONTOUR PILLOW - PHOTOS 1 & 2





The Le Contour pillow uses open-cell foam. Use the following steps to clean:

- 1. Prepare a cleaning solution of one (1) tbsp. of liquid dish detergent and two (2) tbsp. of household bleach with one (1) gallon of water.
- 2. Remove the padding material within the pillow.
- 3. Clean the fabric case exterior and interior surfaces with a sponge or soft cloth dipped in the cleaning solution and then rinse in warm water and let air dry.
- 4. Rinse the padding material with water and then set out to air dry.
- 5. Replace dry cushion into pillow case.

SIMPLY BLISS PILLOW - PHOTOS 3 & 4







The Simply Bliss pillow uses closed-cell foam and requires only occasional external cleaning with a mild soap solution.

SAVE THESE INSTRUCTIONS